

**CRANKSHAFT AND SUPPORTS/FLYWHEEL**

POS.	CODE	DESCRIPTION	Qty
1	«-----»	CRANKSHAFT	0
2	1611.053	bearing -0,50 (tank side)	1
2	1611.054	bearing -0,25 (tank side)	1
2	1611.055	bearing std. (tank side)	1
3	4701.058	gasket 0,30	1
3	4701.059	gasket 0,50	1
4	8675.291	SUPPORT	1
5	1213.347	seal ring 70X88X8	1
6	7626.033	washer	1
7	«-----»	crown gear	0
8	1770.156	bolt M 8 X 1,25 X 25	2
9	«-----»	washer	0
11	2280.056	crankshaft wooddruff key	2
12	9000.073	eXpansion plug	4
13	1770.156	bolt M 8 X 1,25 X 25	6
14	1805.025	bolt	1
15	«-----»	flywheel	0
16	8675.266	gear side support std.	1
16	8675.267	gear side support -0,25	1
16	8675.268	gear side support -0,50	1
17	1610.082	main bearing shell c. std.	1
17	1610.098	main bearing shell c. -0,25	1
17	1610.099	main bearing shell c. -0,50	1
18	9732.075	screw M 8 X 50	2
19	1862.144	bolt	1
20	5111.069	safety plate	1
21	8676.055	MIDDLE SUPPORT	1
22	«-----»	see Pos. G 21	0

C

10LD

