

**CYLINDER HEAD/ROCKER ARM BOX/VALVES**

POS.	CODE	DESCRIPTION	Qty
1	3695.038	safety wire	1
2	8506.003	engine lifting eye	1
3	9731.040	screw M 8 X 60	2
4	9055.003	starter cap	1
5	9032.005	filler oil cap	1
6	«-----»	ring - no longer avail.	0
7	3240.010	nut M 7	1
8	4330.040	ROCKER ARM ASS.Y	1
9	3240.018	nut M 8	2
10	«-----»	safety plate	0
11	3240.010	nut M 7	2
12	«-----»	see Pos. 8	0
13	1240.007	snap ring	2
14	2125.071	rocker arm cover	1
15	4400.019	gasket 0,50	1
16	1160.021	circlip	2
17	3240.125	nut	4
18	9850.002	rocker arm adjuster	1
19	8655.005	rocker arm support	1
20	9850.055	screw	1
21	2135.072	cap	1
22	7701.022	washer	4
23	6410.018	retainer with half-collets	2
24	6800.004	stud M 10 X 20 (35)	2
25	4845.170	inlet v.guide std.	1
25	4845.171	inlet v.guide +0,50	1
26	«-----»	eXhaust v.guide +0,50	0
26	4845.248	eXhaust v.guide std.	1
27	7625.197	washer	4
28	9201.054	CYL.HEAD ASS.Y	1
28	9201.055	CYL.HEAD ASS.Y (for compression release)	1
29	6780.084	stud M 8 X 40 (52)	2
30	9850.002	rocker arm adjuster	1
31	5755.004	valve spring	2
32	8000.031	inlet v.seat	1
33	4730.022	head gasket 0,80	1
33	4730.058	head gasket 1,00	1
33	4730.059	head gasket 0,60	1
33	4730.072	head gasket 0,70	1
33	4730.073	head gasket 0,90	1
34	8000.057	eXhaust v.seat	1
35	6800.050	stud M 10 X 23 (38)	1
36	6800.056	stud M 10 X 28 (43)	1
37	9652.030	intake valve	1
38	9685.040	eXhaust valve	1
39	3430.067	spring seat (bottom)	2

L

7LD

